

FAR NORTH HOBBIES

N.S.W.G RAILWAYS

FMW (NRWF) WAGON

ASSEMBLY:

- 1) Clean all flash from kit and wash in mild detergent to remove release agent.
- 2) Lightly sand all areas that are to be glued. (Suggest using Superglue.)
- 3) Dry fit container to chassis and glue in place, ensuring the ends are flush-
- 4) Take 4 end plates and fit to marked area on ends-fig. 1
- 5) Fit brake cylinder and air reservoir to areas marked.
- 6) Drill holes (.025") in brackets for hand brake, grade control and air release and fit brass wire-fit steps as per sketch.
- 7) Fit bogies (AR Kits 2CL) using 8BA screws- fit Kadee no.5.

PAINTING:

- 1) Chassis - Grimy Black - Floquil
Container- Off White.
- 2) Place Decals as per sketch.

NUMBERS: 23201 - 23211

